

Vacuum Exchange Keeps Cooling System Safe

The 5402/03 Coolant Exchange Machines use shop air to create a vacuum for coolant removal. This process safely removes old coolant without compromising the integrity of the coolant hoses or fittings.

The vacuum removes the old coolant and refills the system with no air pockets. This method is safe for all systems since no pressure is applied to the radiator, water pump, or heater core.

