



CAT Products, Inc

Technical Service Bulletin

Bulletin: 00076

Manufacturer: All

Vehicle: All

Service: Power Steering

Situation-

During a power steering fluid exchange, the technician allows air to get into the hydraulic system. This will create noise and make the steering difficult. TO PREVENT this from occurring, do not remove too much fluid during the exchange process when the engine is running. Keep the suction wand above the power steering fluid output hose.

If air gets in the system, raise the front of the vehicle so the Power Steering Fluid reservoir is higher. With the cap off and the engine off, manually turn the front wheels from side to side several times. This will move the air up and out.