



# Shift-Rite® TFE-6030 DIPSTICK Exchange

TRANSMISSION  
FLUID X-CHANGER  
w/ DIPSTICK MODE




Prior to starting the service, ADD SHIFT-RITE TRANS KLEEN to the old ATF. With the engine running, place your foot on the brake and shift through all of the gears twice. SHUT THE ENGINE OFF and proceed with the service.



## CONNECTION



Connect battery cables to vehicle's battery. Press **2** for Dipstick Exchange





## OPERATION



Connect red and gray service hoses to chrome manifold. Insert nylon tube down dipstick tube the same length as the dipstick, being cautious not to insert too far.


**NOTE:** This machine is fully interactive. Always follow the on-screen instructions.

Use the arrow keys to select the desired amount to be exchanged.



Press to proceed.

Press **1** for No Cleaning, **2** for 5 Min. Cleaning, **3** for 10 Min. Cleaning.




Press to begin exchange.

When display prompts you to do so, **START THE VEHICLE'S ENGINE.** Place your foot on the brake and shift through every gear, pausing 5 seconds between gears.

Press When the exchange is finished, screen will beep and display "Complete".





## ADDITIONAL FEATURES



If needed, while running, pressing once will pause the machine.



Press to resume from pause, or press a second time to cancel exchange.



Check the fluid level.

Press or to add or remove fluid in 2/10 of a quart increments.

Use **Option 3** in the main menu to add a full quart & **Option 4** to remove a full quart.




Press **0** to return to the main menu.

**After the service is complete, add one bottle of SHIFT-RITE TRANS GUARD (or another Shift-Rite ATF Modifier) to the new fluid. Do not overfill.**



## CHANGE VEHICLE'S FILTER



Press **2** when prompted before the exchange, and follow on-screen instructions.

